

GR4808 AND GR4816 SIDE FIXED DRY BALUSTRADE CHANNEL INSTALLATION INSTRUCTIONS

INSTALLATION

PAGE 2

REFER FIGURE 2

- 1 PLACE CHANNEL ON DECK AND MARK THE TWO FURTHEST HORIZONTAL FIXING HOLES
- 2 REMOVE CHANNEL AND PLACE STRING LINE FROM ONE POINT TO HORIZONTAL OPPOSITE POINT
- 3 PLACE H PACKERS WHERE NECESSARY TO ENSURE CHANNEL IS PERFECTLY STRAIGHT
- 4 SILICONE H PACKERS IN PLACE
- 5 PLACE CHANNEL BACK ON DECK AND DRILL FIXING HOLES THROUGH CHANNEL HOLES
- 6 FIT ALL BOLTS AND LIGHTLY TIGHTEN
- 7 PLACE GLASS IN CHANNEL ON RUBBER PACKERS AND LOSELY TIGHTEN GRUB SCREWS
- 8 PLACE LEVEL ON GLASS AND ADJUST HEIGHT WITH GRUB SCREWS UNTIL LEVEL
- 9 RECHECK FOR HEIGHT.PARALLEL AND REPACK IF NECESSARY
- 10 TIGHTEN ALL BOLTS AND GRUB SCREWS SECURELY
- 11 FIT COVER PLATES AND SILICONE TO PREVENT COVERS FROM MOVING
- 12 WHEN JOINING TWO SECTIONS OF CHANNEL IT IS IMPORTANT THAT BOTH SECTIONS ARE IN LINE
- 13 INSTALL WEDGE RUBBER BETWEEN GLASS AND COVER PLATE/S TO PREVENT DUST AND DEBRIS
- 14 FIT LARGE WEDGE RUBBER BETWEEN GLASS PANELS IF REQUIRED